

COFFEE KLEEN



CLEANING TAB



COFFEE MACHINE CLEANING TAB

Art.-No. 90.001.073 60 x 2.4 g

32 cans per carton, 1536 cans per pallet

- Removes coffee oils and greases
- Gentle on materials
- For all fully automatic coffee machines

APPLICATION RANGE:

The COFFEE KLEEN CLEANING TAB removes residues and deposits such as coffee oils and greases in the brewing system reliably and quickly. The gentle cleaning maintains and protects coffee machines and provides for a consistently high coffee quality.

INSTRUCTIONS FOR USE AND DOSAGE:

Device cleaning (normal soiling): 1 tab per cleaning cycle

Device cleaning (heavy soiling): 2 tabs per cleaning cycle

Fully automatic coffee machines: Please follow the user manual of the manufacturer.

Pad and capsule machines: Dissolve a tab in 500 ml of warm water. Soak the sieves, drainage channel and drip tray in the solution and leave to soak for about 5 minutes. Clean fixed parts with the solution. Wipe all parts clean with a cloth and rinse with clean water. Run a cup of water through before use.

Portafilter machine parts: Dissolve a tab in 500 ml warm water and remove and insert sieves and portafilter. Allow all parts to soak for around 30 minutes. Wipe parts clean with a cloth and rinse with clean water. Run a cup of water through before use.

Please observe the cleaning instructions in the user manual of the manufacturer. For professional use only. No liability can be accepted for improper use and any resulting damage. The product should only be used as intended and kept out of the reach of children.

TECHNICAL DATA:

Form: white tab
Diameter: 16 mm
Odour: characteristic
pH-value in 1% dilution: 11

INGREDIENTS:

15-30%: oxygen-based bleaching agents

Stability: at least two years in original containers

Sales Department International:

KLEEN PURGATIS International AG

Firststrasse 30A
CH-8835 Feusisberg
Fon +41 (0) 44 515 35 60
Fax +41 (0) 44 515 35 69
info@coffee-kleen.com
www.coffee-kleen.com

LABELLING:



Warning

Hazard statements: H315: Causes skin irritation.
H319: Causes serious eye irritation.

Precautionary statements: P101: If medical advice is needed, have product container or label at hand.
P264: Wash hands thoroughly after handling.
P305+P351+P338: IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. P337+P313: If eye irritation persists: Get medical advice/attention.

TRANSPORT:

No dangerous good in accordance to the transport regulations (ADR).

Sales Department International:

KLEEN PURGATIS International AG
Firststrasse 30A
CH-8835 Feusisberg
Fon +41 (0) 44 515 35 60
Fax +41 (0) 44 515 35 69
info@coffee-kleen.com
www.coffee-kleen.com