

COFFEE KLEEN



DESCALER



DESCALER

Art.-No. 90.001.076 1 L bottle
6 bottles per carton, 480 bottles per pallet

- Removes scale and deposits
- Gentle on materials
- For all coffee machines and hot water appliances

APPLICATION RANGE:

The COFFEE KLEEN DESCALER combats limescale and deposits in coffee machines and hot water appliances. The descaler is gentle on materials and maintains all appliances.

INSTRUCTIONS FOR USE AND DOSAGE:

Coffee machines:

Fill the water tank with 400 ml of water and add 100 ml of descaler. Place a sufficiently large container under the dispenser. Switch on the machine and rinse until the water tank is completely empty. Drain the collecting vessel. Remove the water tank and rinse it thoroughly. Replace the water tank and rinse the machine again with approx. 1 litre of cold water. Empty the collecting vessel in due time in between.

Hot water appliances:

Fill the appliance with 400 ml of water and add 100 ml descaler. Heat the solution (do not boil) and leave to soak for about 10 - 15 minutes. Then rinse the appliance thoroughly with clean water.

Please observe the instructions for descaling in the user manual of the manufacturer. Do not ingest the descaling solution or any products dispensed during the descaling process. For professional use only. Please check the material compatibility on an insignificant surface before use. No liability can be accepted for improper use and any resulting damage. The product should only be used as intended and kept out of the reach of children.

TECHNICAL DATA:

Form: colourless
Odour: characteristic
Viscosity: low
Density: 1.082 g/cm³
pH-value in concentrate: 2.2

INGREDIENTS:

According to Regulation (EC) No 648/2004, this is not applicable.
Contains sulfamic acid

Stability: at least two years in original containers

Sales Department International:

KLEEN PURGATIS International AG
Firststrasse 30A
CH-8835 Feusisberg
Fon +41 (0) 44 515 35 60
Fax +41 (0) 44 515 35 69
info@coffee-kleen.com
www.coffee-kleen.com

LABELLING:



Warning

Hazard statements: H315: Causes skin irritation.
H319: Causes serious eye irritation.

Precautionary statements: P101: If medical advice is needed, have product container or label at hand.
P280: Wear protective gloves/ eye protection.
P305+P351+P338: IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. P337+P313: If eye irritation persists: Get medical advice/attention.

TRANSPORT:

No dangerous good in accordance to the transport regulations (ADR).

Sales Department International:

KLEEN PURGATIS International AG
Firststrasse 30A
CH-8835 Feusisberg
Fon +41 (0) 44 515 35 60
Fax +41 (0) 44 515 35 69
info@coffee-kleen.com
www.coffee-kleen.com